

XTOOL Shenzhen Xtooltech Co., Ltd

MACK V5.31 Function List

Model	System	Diagnostic interface	Basic diagnosticfunction	Parameter Program	Actuation test	Specific function
V-MAC IV	System auto scan	OBD 6&9	01.System information 02.Read codes 03.Clean codes 04.Read datas	√	Engine ECU: Injector switch off Transmission ECU: Splitter high actuator (VAHS) Splitter low actuator (VAHS) X1 value Brake ECU: Activate the solenoid valve for the ABS,left Activate the solenoid valve for the ABS,right Air Suspension, vehicle: Front axle solenoid valve Lifter airbags solenoid valve Dead axle draining solenoid valve Lock solenoid valve Right live axle solenoid valve Left live axle solenoid valve Central solenoid valve	Engine ECU: Injector code functon Transmission ECU: Calibration of clutch engagement point Clutch initialization (new clutch) Clutch initialization (old clutch) Transmission calibration